



LASER WELDING



Society of
Manufacturing
Engineers



Laser Fundamentals


LASER

- **L**ight **A**mplification by **S**timulated **E**mission of **R**adiation

Active Laser Media (the most common for industrial manufacturing)

- **Nd:YAG (Rod Laser)**
 - Neodymium: Yttrium Aluminum Garnet
- **Yb:YAG (Disk Laser)**
 - Ytterbium: Yttrium Aluminum Garnet
- **CO₂ (Gas Laser)**

Principle of LASER



Pump Sources:

High Voltage
Flashlamp
Diode

Laser Active Medium:

Gas
Rod
Fiber
Disk


Wavelength:

CO ₂	10.6 μm
Nd:YAG	1.064 μm
Yb:YAG	1.030 μm




Society of
Manufacturing
Engineers


Conventional Optics



Fiber Optics



Principle of Laser Processing



Laser beam

Wavelength (μm)
Power (W)
Irradiance (W/cm^2)
Energy (J)
Interaction time/ pulse duration (ms)
Beam quality (mm mrad)

Optics

Focussing length/distance to surface
Fiber core diameter
Beam shaping

Gas

Type/mixture/purity
Velocity/distance nozzle - surface

Material

Surface	bulk properties
Absorption	material type
Roughness	thickness
Temperature	heat conduction
Dirt	heat capacity
Melt property	microstructure
-tension	
-chem. reactions	

Principles of Laser Welding

Heat conduction welding

Heating of the workpiece for temperatures above the melting temperature without vaporizing, power density from $10^4 - 10^5 \text{ W/cm}^2$


Welding depth depends on heat conduction

Characteristics

- Low welding depth
- Small aspect ratio
- Low coupling efficiency

Applications

Laser welding of thin workpieces like foils, wires, thin tubes, etc.



Society of
Manufacturing
Engineers


Principle of laser processing

Deep welding

Heating of the workpiece above the evaporating temperature and creation of a keyhole because of the ablation pressure of the flowing metal vapor, power density of $10^5 - 10^6 \text{ W/cm}^2$

Characteristics

- High welding depth
- Large aspect ratio
- High coupling efficiency



Society of
Manufacturing
Engineers



Advantages of laser welding

- **Minimum heat input and high aspect ratio resulting in ...**
 - > *minimal shrinkage & distortion of the workpiece*
 - > *small heat affected zone*
 - > *narrow weld bead with good appearance*

- **High strength welds often resulting in ...**
 - > *improved component stiffness / fatigue strength*
 - > *reduction of component size / weight*
 - > *continuous weld possible*

- **Ability to weld in areas difficult to reach with other techniques**
 - > *non-contact, narrow access, single sided process*

- **Easily automated with accurately located welds**
 - > *consistent weld penetration / weld geometry / weld quality*
 - > *ability to integrate into existing equipment / production lines*



Society of
Manufacturing
Engineers



Advantages of laser welding

■ Flexibility ...

- > *beam manipulation (beam switching and sharing)*
- > *variety of part & weld geometries and materials*
- > *ease of back-up (especially YAG)*

■ Often faster than other techniques ...

- > *high power density weld process*
- > *high laser uptime (>98%)*

■ Cost savings ...

- > *high productivity >> faster cycle time = less stations*
- > *reduction of scrap and re-work*
- > *reduction of manual labor*
- > *reduction of component material and weight*
- > *can eliminate secondary processes*



Laser Welding Aneurysm Clip

(Alternating) Spot welding with scanner optics

Material: Titanium

Laser parameters:

- Average power $P_{av} = 60 \text{ W}$

Benefit:

- Distortion-free weld connections
- Optimal clip guidance
- Perfect shape and smooth surface
- Best possible biocompatibility






Laser Welding Ophthalmic Device

40um wide weld on 50um thick wires
for ophthalmic device

Material: Stainless Steel

Energy: 50 mJ/pulse

Speed: 8 mm/min




Slide provided by GSI Group, www.gsiglasers.com




Society of
Manufacturing
Engineers

Laser Welding IT Plugs



Material: Cu

Comments: Special Pulse Form



Slide Provided by LASAG / www.lasag.com



Society of
Manufacturing
Engineers



Laser Welding Retrieval Basket

Materials: Stainless + Nitinol


- Ø 650 µm (Stainless jacket)
- Ø 400 µm (Stainless wire)
- Ø 150 µm (Nitinol wire)

Laser pulse parameters:

- $P_p = 700 \text{ W}$ at $\tau = 4 \text{ ms}$

Benefits:


- Low heat input
- High stability of all joints (up to 70 N test pressure)



Vascular Clamps


Material: Stainless Steel

Energy: ~ 2 Joules
Single Pulse





Laser Welding Heat Sinks on Lead Frames




Material: CuFe₂P

Parameters: 20Hz, 3 ms, 2 Joules

Spot Size: 300 μm (0.011")

Comments: Special Pulse Form





Slide Provided by LASAG / www.lasag.com



Society of
Manufacturing
Engineers

Laser Welding Pacemakers



Material: Titanium Grade 2

Feed Rate: 1.2 m/min (47.2 in./min.)

Comments: Pulse form, modulated, low HAZ

Slide Provided by LASAG / www.lasag.com



Society of
Manufacturing
Engineers



Marker Bands- spot welded over lead

Material: Platinum

Energy: ~ 0.5 Joules
Single Spot



Slide provided by GSI Group, www.gsiglasers.com



Society of
Manufacturing
Engineers




Laser Welding Markers on Stents

Material: Nitinol and Tantalum

Pulse Energy: 0.065 Joules

Feed Rate: 100 mm/min (4 in./min.)

Comments: Pulse form, modulated, trailing edge



Slide Provided by LASAG / www.lasag.com



Society of
Manufacturing
Engineers



Laser Welding Endoscope

Two smaller tubes are welded simultaneously on one big tube

Material: Stainless 1.4301

Laser parameters:


- Average power $P_{av} = 120 \text{ W}$
- Speed 150 mm/min

Benefit:

- Virtually distortion-free welds
- Free motion of the guide wires



Laser Welding Endoscopes



Material: Nitinol and Stainless Steel

Laser Parameters: 20Hz / 2 ms / 1.6 Joules

Spot Size: 400um (0.015")

Cycle Time: 6 sec.



Laser Welding Pacemaker Battery


Material: Stainless Steel

Energy: ~ 0.3 Joule (lid)
~ 0.25 Joule (feed-through)

Speed: ~ 75 in/min (lid)
~ 10 in/min (feed-through)

Glass-to-Metal Feed-Through Weld

Lid Weld




Slide provided by GSI Group, www.gsiglasers.com



Society of
Manufacturing
Engineers



Laser Welding Radioactive Prostate Seeds




Material: Titanium

Wall Thickness: 0.04 mm (0.0015")

Tube Diameter: 0.8 mm (0.0315")

Comments: Hermetic Sealed




Slide Provided by LASAG / www.lasag.com



Society of
Manufacturing
Engineers



Laser Welding Radioactive Prostate Seeds



Material: Titanium

Wall Thickness: 0.1 mm (0.004")

Tube Diameter: 0.75 mm (0.0315")

Comments: Hermetic Sealed

Slide provided by GSI Group, www.gsiglasers.com



Society of
Manufacturing
Engineers



Keys to success

- **Design components for laser welding**
(flange widths, gauge thicknesses, single sided access)
- **Maximize laser “beam on” time**
(i.e. time sharing of beam to multiple stations)
- **Good part fit-up via part tolerances & fixturing**
Butt weld: edge preparation, gap < 10% of t_{\min} , seam location
Overlap weld: gap < 10% of t_{\min}
- **Parts must be clean & dry for optimum results**
(no dirt, rust, grease, heavy oils, sand residue, paint/primer, adhesives, sealers, water, solvent)
- **Assign laser welding champion at using plant**
(engineer, attitude/aptitude, teachable, can teach others)
- **Early involvement of production personnel**
(ownership, design for service & maintenance)
- **Commitment to training & spare parts**
(ownership, design for service & maintenance)
- **Partner with suppliers that have proven expertise, longevity & reputation**



Society of
Manufacturing
Engineers